

```
1 # USAGE
2 # To read and write back out to video:
3 # python people_counter.py --prototxt mobilenet_ssd/MobileNetSSD_deploy.prototxt \
4 #     --model mobilenet_ssd/MobileNetSSD_deploy.caffemodel --input
5 #     videos/example_01.mp4 \
6 #     --output output/output_01.avi
7 #
8 # To read from webcam and write back out to disk:
9 # python people_counter.py --prototxt mobilenet_ssd/MobileNetSSD_deploy.prototxt \
10 #     --model mobilenet_ssd/MobileNetSSD_deploy.caffemodel \
11 #     --output output/webcam_output.avi
12
13 # import the necessary packages
14 from pyimagesearch.centroidtracker import CentroidTracker
15 from pyimagesearch.trackableobject import TrackableObject
16 from imutils.video import VideoStream
17 from imutils.video import FPS
18 import numpy as np
19 import argparse
20 import imutils
21 import time
22 import dlib
23 import cv2
24
25 # construct the argument parse and parse the arguments
26 ap = argparse.ArgumentParser()
27 ap.add_argument("-p", "--prototxt", required=True,
28                 help="path to Caffe 'deploy' prototxt file")
29 ap.add_argument("-m", "--model", required=True,
30                 help="path to Caffe pre-trained model")
31 ap.add_argument("-i", "--input", type=str,
32                 help="path to optional input video file")
33 ap.add_argument("-o", "--output", type=str,
34                 help="path to optional output video file")
35 ap.add_argument("-c", "--confidence", type=float, default=0.4,
36                 help="minimum probability to filter weak detections")
37 ap.add_argument("-s", "--skip-frames", type=int, default=30,
38                 help="# of skip frames between detections")
39 args = vars(ap.parse_args())
40
41 # initialize the list of class labels MobileNet SSD was trained to
42 # detect
43 CLASSES = ["background", "aeroplane", "bicycle", "bird", "boat",
44            "bottle", "bus", "car", "cat", "chair", "cow", "diningtable",
45            "dog", "horse", "motorbike", "person", "pottedplant", "sheep",
46            "sofa", "train", "tvmonitor"]
47
48 # Load our serialized model from disk
49 print("[INFO] loading model...")
50 net = cv2.dnn.readNetFromCaffe(args["prototxt"], args["model"])
51
52 # if a video path was not supplied, grab a reference to the webcam
53 if not args.get("input", False):
54     print("[INFO] starting video stream...")
55     vs = VideoStream(src=0).start()
56     time.sleep(2.0)
57
58 # otherwise, grab a reference to the video file
```

```
58 else:
59     print("[INFO] opening video file...")
60     vs = cv2.VideoCapture(args["input"])
61
62 # initialize the video writer (we'll instantiate later if need be)
63 writer = None
64
65 # initialize the frame dimensions (we'll set them as soon as we read
66 # the first frame from the video)
67 W = None
68 H = None
69
70 # instantiate our centroid tracker, then initialize a list to store
71 # each of our dlib correlation trackers, followed by a dictionary to
72 # map each unique object ID to a TrackableObject
73 ct = CentroidTracker(maxDisappeared=40, maxDistance=50)
74 trackers = []
75 trackableObjects = {}
76
77 # initialize the total number of frames processed thus far, along
78 # with the total number of objects that have moved either up or down
79 totalFrames = 0
80 totalDown = 0
81 totalUp = 0
82
83 # start the frames per second throughput estimator
84 fps = FPS().start()
85
86 # loop over frames from the video stream
87 while True:
88     # grab the next frame and handle if we are reading from either
89     # VideoCapture or VideoStream
90     frame = vs.read()
91     frame = frame[1] if args.get("input", False) else frame
92
93     # if we are viewing a video and we did not grab a frame then we
94     # have reached the end of the video
95     if args["input"] is not None and frame is None:
96         break
97
98     # resize the frame to have a maximum width of 500 pixels (the
99     # less data we have, the faster we can process it), then convert
100     # the frame from BGR to RGB for dlib
101     frame = imutils.resize(frame, width=500)
102     rgb = cv2.cvtColor(frame, cv2.COLOR_BGR2RGB)
103
104     # if the frame dimensions are empty, set them
105     if W is None or H is None:
106         (H, W) = frame.shape[:2]
107
108     # if we are supposed to be writing a video to disk, initialize
109     # the writer
110     if args["output"] is not None and writer is None:
111         fourcc = cv2.VideoWriter_fourcc(*"MJPG")
112         writer = cv2.VideoWriter(args["output"], fourcc, 30,
113                                 (W, H), True)
114
115     # initialize the current status along with our list of bounding
116     # box rectangles returned by either (1) our object detector or
```

```
117     # (2) the correlation trackers
118     status = "Waiting"
119     rects = []
120
121     # check to see if we should run a more computationally expensive
122     # object detection method to aid our tracker
123     if totalFrames % args["skip_frames"] == 0:
124         # set the status and initialize our new set of object trackers
125         status = "Detecting"
126         trackers = []
127
128         # convert the frame to a blob and pass the blob through the
129         # network and obtain the detections
130         blob = cv2.dnn.blobFromImage(frame, 0.007843, (W, H), 127.5)
131         net.setInput(blob)
132         detections = net.forward()
133
134         # loop over the detections
135         for i in np.arange(0, detections.shape[2]):
136             # extract the confidence (i.e., probability) associated
137             # with the prediction
138             confidence = detections[0, 0, i, 2]
139
140             # filter out weak detections by requiring a minimum
141             # confidence
142             if confidence > args["confidence"]:
143                 # extract the index of the class label from the
144                 # detections list
145                 idx = int(detections[0, 0, i, 1])
146
147                 # if the class label is not a person, ignore it
148                 if CLASSES[idx] != "person":
149                     continue
150
151                 # compute the (x, y)-coordinates of the bounding box
152                 # for the object
153                 box = detections[0, 0, i, 3:7] * np.array([W, H, W, H])
154                 (startX, startY, endX, endY) = box.astype("int")
155
156                 # construct a dlib rectangle object from the bounding
157                 # box coordinates and then start the dlib correlation
158                 # tracker
159                 tracker = dlib.correlation_tracker()
160                 rect = dlib.rectangle(startX, startY, endX, endY)
161                 tracker.start_track(rgb, rect)
162
163                 # add the tracker to our list of trackers so we can
164                 # utilize it during skip frames
165                 trackers.append(tracker)
166
167     # otherwise, we should utilize our object *trackers* rather than
168     # object *detectors* to obtain a higher frame processing throughput
169     else:
170         # loop over the trackers
171         for tracker in trackers:
172             # set the status of our system to be 'tracking' rather
173             # than 'waiting' or 'detecting'
174             status = "Tracking"
175
```

```
176         # update the tracker and grab the updated position
177         tracker.update(rgb)
178         pos = tracker.get_position()
179
180         # unpack the position object
181         startX = int(pos.left())
182         startY = int(pos.top())
183         endX = int(pos.right())
184         endY = int(pos.bottom())
185
186         # add the bounding box coordinates to the rectangles List
187         rects.append((startX, startY, endX, endY))
188
189     # draw a horizontal line in the center of the frame -- once an
190     # object crosses this line we will determine whether they were
191     # moving 'up' or 'down'
192     cv2.line(frame, (0, H // 2), (W, H // 2), (0, 255, 255), 2)
193
194     # use the centroid tracker to associate the (1) old object
195     # centroids with (2) the newly computed object centroids
196     objects = ct.update(rects)
197
198     # Loop over the tracked objects
199     for (objectID, centroid) in objects.items():
200         # check to see if a trackable object exists for the current
201         # object ID
202         to = trackableObjects.get(objectID, None)
203
204         # if there is no existing trackable object, create one
205         if to is None:
206             to = TrackableObject(objectID, centroid)
207
208         # otherwise, there is a trackable object so we can utilize it
209         # to determine direction
210         else:
211             # the difference between the y-coordinate of the *current*
212             # centroid and the mean of *previous* centroids will tell
213             # us in which direction the object is moving (negative for
214             # 'up' and positive for 'down')
215             y = [c[1] for c in to.centroids]
216             direction = centroid[1] - np.mean(y)
217             to.centroids.append(centroid)
218
219             # check to see if the object has been counted or not
220             if not to.counted:
221                 # if the direction is negative (indicating the object
222                 # is moving up) AND the centroid is above the center
223                 # line, count the object
224                 if direction < 0 and centroid[1] < H // 2:
225                     totalUp += 1
226                     to.counted = True
227
228                 # if the direction is positive (indicating the object
229                 # is moving down) AND the centroid is below the
230                 # center line, count the object
231                 elif direction > 0 and centroid[1] > H // 2:
232                     totalDown += 1
233                     to.counted = True
234
```

```
235         # store the trackable object in our dictionary
236         trackableObjects[objectID] = to
237
238         # draw both the ID of the object and the centroid of the
239         # object on the output frame
240         text = "ID {}".format(objectID)
241         cv2.putText(frame, text, (centroid[0] - 10, centroid[1] - 10),
242                     cv2.FONT_HERSHEY_SIMPLEX, 0.5, (0, 255, 0), 2)
243         cv2.circle(frame, (centroid[0], centroid[1]), 4, (0, 255, 0), -1)
244
245     # construct a tuple of information we will be displaying on the
246     # frame
247     info = [
248         ("Up", totalUp),
249         ("Down", totalDown),
250         ("Status", status),
251     ]
252
253     # Loop over the info tuples and draw them on our frame
254     for (i, (k, v)) in enumerate(info):
255         text = "{}: {}".format(k, v)
256         cv2.putText(frame, text, (10, H - ((i * 20) + 20)),
257                     cv2.FONT_HERSHEY_SIMPLEX, 0.6, (0, 0, 255), 2)
258
259     # check to see if we should write the frame to disk
260     if writer is not None:
261         writer.write(frame)
262
263     # show the output frame
264     cv2.imshow("Frame", frame)
265     key = cv2.waitKey(1) & 0xFF
266
267     # if the `q` key was pressed, break from the loop
268     if key == ord("q"):
269         break
270
271     # increment the total number of frames processed thus far and
272     # then update the FPS counter
273     totalFrames += 1
274     fps.update()
275
276 # stop the timer and display FPS information
277 fps.stop()
278 print("[INFO] elapsed time: {:.2f}".format(fps.elapsed()))
279 print("[INFO] approx. FPS: {:.2f}".format(fps.fps()))
280
281 # check to see if we need to release the video writer pointer
282 if writer is not None:
283     writer.release()
284
285 # if we are not using a video file, stop the camera video stream
286 if not args.get("input", False):
287     vs.stop()
288
289 # otherwise, release the video file pointer
290 else:
291     vs.release()
292
293 # close any open windows
```

```
294 | cv2.destroyAllWindows()
```